

INSTRUCTION for the Pocket WiFi(GL04Pver1.0)

1. Charge Battery

- a) From wall socket (outlet). Full charge takes 3 hours
- b) From PC (USB)
Full charge takes 7.5 hours

2. Power On/Off

- Push Power button for 5sec to turn on the device. The device will automatically connect to 3G/LTE.
- Push Power button for 5sec. to turn off.



★ Saving Mode ★

Pocket WiFi will automatically switch to energy saving mode if not used for 10min. To turn it back on, press the power button for 1sec. Then appear Wifi indicator on the screen.

3. Set up Wi-Fi for Laptop or iPhone/iPad

a) For Laptop

- Select Control Panel from “Start Menu”
- Select “Network and Sharing Center”, then click Connect to Network.
- Select SSID “GL04P-xxxx” or back of the pocket wifi then click connect.
- Type in WPA key. Your WPA key is on the back of Pocket Wi-Fi device. Then save.

b) For iPhone/iPad

- Select Settings icon and General, then touch “Network” and Wi-Fi.
- Select SSID “GL04P-xxxx” or back of the pocket wifi then click connect.
- Type in WPA key. Your WPA key is on the back of Pocket Wi-Fi device. Then save.

4 Reset Pocket Wi-Fi

If you have Power Button e any issues,
Please push Power Button more then 10 sec.
Then Turn on Wifi Power
And press Reset Button for 2-3 secounds.
The WiFi will automatically restart.



Return Checklist

1. Pocket Wi-Fi device.
2. AC charger
3. USB cable
4. This Manual

- Prohibited Actions -

- Do not open Pocket Wi-fi.
- Do not remove SIM Card from the device.
- Do not use the device outside Japan. If you do, you will be charged the expensive roaming fee.

Support center

Phone 03-5843-7925 or 080-3452-7100

(Start from the other side)